



FYM2000 Connector Map

3 Channel 100W Version

(Suits JCM2000 TSL100, TSL122 Models Only)

Main PCB	Front Top PCB (Crunch Ch.)	Front Mid PCB (Clean Ch.)	Front Bot PCB (Lead Ch.)	Reverb PCB	Rear PCB (spk / FX etc)	Other (descr.)
CON1						Bias Trimpot PCB
CON2		CON1				
CON3		CON6				
CON4			CON8			
CON5			CON4			
CON6		CON2				
CON7			CON15			
CON8				CON1		
CON9			CON11			
CON10					CON6	
CON11			CON12			
CON12			CON20			
CON13			CON18			
CON14					CON2	
	CON1		CON5			
	CON2		CON6			
	CON3		CON9			
	CON4		CON14			
	CON5		CON17			
		CON3	CON7			
		CON4	CON10			
		CON5	CON1			
			CON13	CON2		
			CON16		CON3	
			CON19		CON19	
				CON3	CON4	
W1						CHASSIS GND (GREEN)
W2					W4	NEGATIVE FB (YELLOW)
W3						OT PLATE (WHITE)
W4						OT PLATE (PURPLE)
W5						OT CT (BLUE)
W6						PT HV (TO FUSE W15, PINK)
W7						PT HV (PURPLE)
W8						N/C
W9						PT HEATER (RED)
W10						PT HEATER (RED)
W11						PT LV (WHITE)
W12						PT LV CT (BLACK)
W13						PT LV (WHITE)
W14						CHASSIS GND (GREEN)

Notes:
